

V-SFT Ver. 5/ Ver. 6 Update Procedure  
(for Windows Vista/ 7/ 8/ 8.1)

This document explains how to update your V-SFT,  
after installing on Windows Vista/ 7/ 8/ 8.1 using CD-ROM Ver. 5.4.19.0 or earlier.

Windows Vista/ 7 (32-bit) Ver. 5.4.11.0~  
Windows Vista/ 7 (64-bit) Ver. 5.4.19.0~  
Windows 8 (32-bit, 64-bit) Ver. 5.4.28.0~  
Windows 8.1 (32-bit, 64-bit) Ver. 5.4.37.0~

Hakko Electronics Co., Ltd.  
The sixth edition  
March, 2016

Update Procedure (for Windows Vista/ 7/ 8/ 8.1)

<Points to be checked before installing V-SFT or POD EDITOR >

With V-SFT Ver. 5.4.11.0 or later, the default path of V-SFT Ver. 5/ Ver. 6 will be changed as follows:

Ver. 5.4.10.0 or earlier	Ver. 5.4.11.0 or later	Ver. 6
All OS: C:¥Program Files¥ *****  V-SFT V5 --- V-SFT Ver. 5 V-SFT V3 --- V-SFT Ver. 3 V6W --- V-SFT Ver. 2/ 1 UG00S-CWV5 --- POD EDITOR Ver. 5 UG00S-CWV4 --- POD EDITOR Ver. 4 UGW --- POD EDITOR Ver. 3	Windows XP or earlier OS: C:¥Program Files¥V-SFT V5  Windows Vista/ 7/ 8/ 8.1: C:¥MONITOUCH¥V-SFT V5	All OS: C:¥MONITOUCH  * Three folders, "Common", "User" and "V-SFT V6" are created.

\* If installing V-SFT Ver. 5 in "C:¥Program Files" on Windows Vista/ 7/ 8/ 8.1, it may not work properly.

Check both OS for computer and CD-ROM/ DVD-ROM Version for V-SFT or UG00S-CW before installing it. Then perform the installation by following the instructions of (1) to (3) in the table below.

		V-SFT CD-ROM/ DVD-ROM Version		
OS	Windows Vista/ 7/ 8/ 8.1 32-bit	Ver. 2.0.0.0 to 2.2.42.0 Ver. 3.0.0.0 to 3.0.15.0 (1)	Ver. 2.2.43.0 to 2.2.45.0 Ver. 3.0.16.0 to 3.0.24.0 Ver. 5.0.0.0 to 5.4.10.0 (2)	Ver. 5.4.11.0 or later Ver. 6.0.0.0 or later (3)
	Windows Vista/ 7/ 8/ 8.1 64-bit	Ver. 2.2.42.0 or earlier (1)	Ver. 2.2.43.0 to 5.4.18.0 (2)	Ver. 5.4.19.0 or later Ver. 6.0.0.0 or later (3)

		UG00S-CW CD-ROM Version	
OS	Windows Vista/ 7/ 8/ 8.1 32-bit	Ver. 3.0.0.0 to 3.2.33.0 Ver. 4.0.0.0 to 4.0.10.0 (1)	Ver. 4.0.11.0 to 4.0.17.2 Ver. 5.0.0.0 to 5.0.10.3 (2)
	Windows Vista/ 7/ 8/ 8.1 64-bit	Ver. 3.0.0.0 to 3.2.33.0 (1)	

- (1) This CD-ROM is not available. Please purchase the newest version of V-SFT DVD-ROM.
- (2) Install V-SFT or UG00S-CW by following the procedure explained in this manual. For details, refer to the "Install Procedure" on page 3.
- (3) This manual is not necessary for you. Install V-SFT in the PC by following the instructions of the installer. When updating V-SFT, refer to the "Update Procedure" on page 6.

## Update Procedure (for Windows Vista/ 7/ 8/ 8.1)

### <Install Procedure>

\* Install the V-SFT editor with authorization of administrator.

#### 1. Uninstallation of V-SFT Ver. 5

If V-SFT Ver. 5 is already installed on Windows Vista/ 7/ 8/ 8.1, you have to uninstall V-SFT Ver. 5. Click [Start] Menu → [All Programs] → [V-SFTV5] → [Uninstall]. About the details of uninstalling, refer to “V8 series Introductory Manual”.

If V-SFT Ver. 5 is not installed, go to step 2.

#### 2. Run “setup.exe” in the V-SFT/ POD EDITOR CD-ROM.

Insert your V-SFT CD-ROM or POD EDITOR CD-ROM in the PC.

When the following dialog is displayed, click “INSTALL”.

Example: V-SFT Ver. 5



Update Procedure (for Windows Vista/ 7/ 8/ 8.1)

3. Change the installing directory

If your CD-ROM is V-SFT Ver. 5, click “Change...” on [Choose Destination Location] dialog.

Change the destination from the default “C:\Program Files\V-SFT V5” to as follows:

\* If you have V-SFT CD-ROM Ver. 3/ 2, or POD EDITOR CD-ROM Ver. 5/ 4, you do not have to change the destination.

However, V-SFT Ver. 3/ 2 or POD EDITOR Ver. 5/ 4 installed on Windows Vista/ 7/ 8/ 8.1, can not be used because these may not work properly.

[Destination folder]

< Before change >


C:\Program Files\V-SFT V5

< After change >

C:\MONITOUCH\V-SFT V5


Alphabets

a space



4. Start installation

On [Ready to Install the Program], click “Install” to start the installation.



5. Implementation of update

Upon completion of the installation in the step 4, update V-SFT editor.

Refer to “Update Procedure” on page 6.

## Update Procedure (for Windows Vista/ 7/ 8/ 8.1)


<Update Procedure>

\* Install the V-SFT editor with authorization of administrator.

Execute “update\_v5.exe” or “V-SFT V6\_update\_V6xxx.EXE” downloaded from our website and follow the installer for instructions.

Do not change the destination from the default.

Example: V-SFT Ver. 5



V-SFT Ver. 5/ Ver. 6 is ready to use on Windows Vista/ 7/ 8/ 8.1 once installation is completed.

(Note)

When updating V-SFT to Ver. 6, it is necessary to download manuals for Help menu from our website.

Execute “VSFTV6\_Manual.EXE” download from our website and follow the installer for instructions.