

Printer type			MONITOUCH type						Remarks
Manufacturer	Model	Printer port	Interface	V10	/V9	X1	TS2060	V8	
<b>PR-201</b>									
-	Any models compatible with MS-DOS and control codes of PC-PR201	Parallel	USB-A	✓	✓	-	✓ *1	✓	*2
		Serial	MJ1/MJ2	✓	✓	-	✓	✓	
<b>ESC-P</b>									
SEIKO EPSON	LP-S280DN (Monochrome laser printer)	USB-B	USB-A	✓	✓	-	*3	*3	V9 : OS Ver. 3.30 or later
	PX-S170T	USB-B	USB-A	✓	✓		✓	✓	V9 : OS Ver. 4.00 or later
	VP-D500 (Dot impact printer)	Parallel	USB-A	✓	✓	-	✓ *1	✓	*2
		Serial	MJ1/MJ2	✓	✓	-	✓	✓	
-	Any models compatible with MS-DOS and control codes of ESC/P24-J84, ESC/P-J84, or ESC/P Super	Parallel	USB-A	✓	✓	-	✓ *1	✓	*2
		Serial	MJ1/MJ2	✓	✓	-	✓	✓	
<b>CBM-292/293</b>									
CITIZEN SYSTEMS	CT-P292/293	Serial	MJ1/MJ2	✓	✓	-	✓	✓	*4
NADA ELECTRONICS	MPT-262F	Serial	MJ1/MJ2	✓	✓	-	*3	*3	*4 *5
	MP-192	Serial	MJ1/MJ2	✓	✓	-	✓	✓	*4 *5
<b>SK1-41/31/21/22/24</b>									
Sanei Electric	SK1-41/31/21/22/24	Serial	MJ1/MJ2	✓	✓	-	-	-	V9 : OS Ver. 1.40 or later
		USB-B	USB-A	✓	✓	-	-	-	V9 : OS Ver. 1.40 or later
<b>MR-400</b>									
SATO	M-48Pro8	Serial	MJ1/MJ2	✓	✓	-	✓	✓	*6
<b>EPSON ESC/P-R</b>									
SEIKO EPSON	PX-S170T (Color inkjet printer)	USB-B	USB-A	✓	✓	-	-	-	V9 : OS Ver. 4.00 or later
		LAN	Ethernet	✓	✓	-	-	-	V9 : OS Ver. 4.00 or later
	EP-315 PX-S505, PX-S155 PX-S161T, PX-M161T, PX-S730	USB-B	USB-A	*3	-	-	-	-	V10 : OS Ver. 1.40 or later
		LAN	Ethernet	*3	-	-	-	-	V10 : OS Ver. 1.40 or later
<b>HP HPLIP</b>									
HP	Supporting HPLIP version up to 3.18.6	USB-B	USB-A	✓	✓	-	-	-	V9 : Hardware Ver. f or later, OS Ver. 4.00 or later
		LAN	Ethernet	✓	✓	-	-	-	V9 : Hardware Ver. f or later, OS Ver. 4.00 or later
<b>OKI COREFIDO</b>									
OKI	B432dnw (Monochrome LED printer)	USB-B	USB-A	✓	✓	-	-	-	V9 : OS Ver. 4.20 or later
		LAN	Ethernet	✓	✓	-	-	-	V9 : OS Ver. 4.20 or later
<b>PictBridge-compatible printer</b>									
-	PictBridge-compatible printer	USB-A	USB-B	*3	*3	-	*3	*3	
<b>None</b>									
-	Any models compatible with Windows 10 *7	USB-B	USB-A	-	-	✓	-	-	
		LAN	Ethernet	-	-	✓	-	-	

\*1 Connectable with TS2060i only. (TS2060 does not have a USB-A port.)  
 \*2 Use a USB-parallel conversion cable, "UC-PGT" from ELECOM for parallel connection to USB-A.  
 \*3 Unverified  
 \*4 Screen images cannot be printed.  
 \*5 Character graphics cannot be used for data sheet printing.  
 \*6 Barcode printing only  
 \*7 Install the printer driver using System Configurator. For details, refer to the X1 Series Hardware Specifications manual.